# Vision-Link<sup>®</sup> light



Protecting you for life's best moments.

TECHNICAL DATA SHEET G

GVS-RPB.COM

The Vision-Link is a rechargeable chin mounted light that can be attached to the RPB<sup> $\circ$ </sup> Z-Link<sup> $\circ$ </sup>, T-Link<sup> $\circ$ </sup>, and Z4<sup> $\circ$ </sup> series of industrial respirators, without adding any additional height or unnecessary weight to the respirator.

It offers a high output, focused light for people working in low light areas.

Part number 16-910

**Type description** Respirator mounted light.

**Compatible with** T-Link , Z-Link, and Z4 (mounting brackets included).

Application Ranges (including but not limited to the following) Any industrial application with a low light environment, e.g. night shifts, confined space work, site work/awkward area's for welding, grinding, painting and wherever the Z-Link, T-Link, and Z4 are used.

Warranty

1 year. Conditions apply, visit gvs-rpb.com/legal for full details.

## Maintenance

- Recharge the battery as needed.
- Replace the protective lens and battery cowling seal as needed.

Parts	Part #
Replacement lens with screws	16-916
Battery cowling seal	16-915



RPB Vision-Link helmet light.

# **Specifications**

Battery	Part #
Custom 18650 lithium-ion battery 3.6V	09-055
USB powered 2 slot charging unit	09-050
Run time of up to 4 hours.	

### Materials

Nylon	Housing
Santoprene	Overmold, gasket
Polycarbonate	Lens
Litium-ion	Rechargeable battery

### Light

650 Lumens

#### Weight

0.22lbs / 100g (including battery)

# Operating temperature

14°F to 140°F (-10°C to 60°C)

#### Storage temperature

14°F to 113°F (-10°C to 45°C) <90%rh Recommended storage temperature is 40°F to 70°F (4°C to 21°C) in order to maximize the life of the battery.

#### Transportation

Assemblies with batteries ship following UN3481 requirements. Batteries shipped separately must follow UN3480 requirements.

# Vision-Link<sup>®</sup> light



Protecting you for life's best moments.

TECHNICAL DATA SHEET

GVS-RPB.COM



**Employers** Read the Vision-Link and respirator headtop instruction manuals and carry out the employer responsibilities. Provide the manuals to all users.

**Product users** 

Read the Vision-Link and respirator headtop instruction manuals and follow the product user safety instructions.

Manuals are regularly updated.

# Current version of manual and for other languages: <u>gvs-rpb.com/resources</u>

**Contact** RPB Safety - Global Headquarters 2807 Samoset Rd, Royal Oak, MI 48073, USA T: 1-866-494-4599 E-mail: sales@gvs.com

gvs-rpb.com